STARTING & CHARGING

TORQUE SPECIFICATION

031TH–01

Part Tightened	N·m	kgf·cm	ft·lbf
Battery hold down clamp x Body	5.4	55	48 in.·lbf
Battery hold down clamp x Battery tray	5.4	55	48 in.·lbf
Fusible link block assy x Battery	6.0	61	53 in.·lbf
Quarter vent duct No. 2 x Body	4.0	41	35 in.·lbf
Engine wire No. 3 (battery negative terminal) x Battery	6.0	61	53 in.·lbf