DTC	P0AA4/232	HYBRID BATTERY NEGATIVE CONTACTOR CIRCUIT STUCK CLOSED

CIRCUIT DESCRIPTION

Refer to DTC P0AA1 (INF 224) on page 05–537.

DTC No.	INF Code	DTC Detection Condition	Trouble Area
P0AA4	232	System main relay terminal of HV battery negative side stuck closed	• System main relay No. 3

INSPECTION PROCEDURE

If the information (INF) code is present, replace the system main relay No. 3.

REPLACE SYSTEM MAIN RELAY NO. 3 (See page 21–92)