05IG9–01

HOW TO PROCEED WITH TROUBLESHOOTING

The intelligent tester II can be used at step 3, 4, 5, 8.

1	VEHICLE BROUGHT TO WORKSHOP

2	CUSTOMER PROBLEM ANALYSIS (See page 05–648)

3	CONNECT INTELLIGENT TESTER II TO DLC3

HINT:
If the display indicates a communication fault in the tester, inspect the DLC3.

4	CHECK AND RECORD DTC AND FREEZE FRAME DATA (See page 05–657)

HINT:
If a DTC related to the CAN communication system malfunction is output, first troubleshoot and repair the CAN communication (see page 05–2312).

5	CLEAR DTC (See page 05–657)

6	PROBLEM SYMPTOM CONFIRMATION

(a) When the malfunction does not occur, go to A.
(b) When the malfunction occurs, go to B.

B	Go to step 8

A

7	SYMPTOM SIMULATION

8	CHECK DTC (See page 05–657)

9	DTC CHART (See page 05–665)

10	**CIRCUIT INSPECTION**

11	**IDENTIFICATION OF PROBLEM**

12	**ADJUSTMENT AND/OR REPAIR**

13	**CONFIRMATION TEST**

END