05IJ6-01

HOW TO PROCEED WITH TROUBLESHOOTING

The intelligent tester II can be used at step 3, 6, 9, 12.

1	Vehicle Brought to Workshop

2	Customer Problem Analysis (SEE PAGE 05–717)

3	Check and Clear DTCs and Freeze Frame Data (SEE PAGE 05–738)

4	Problem Symptom Confirmation

→ Symptom does not occur: Go to step 5

→ Symptom occur: Go to step 6

5	Symptom Simulation (SEE PAGE 01–46)

6	DTC Check (SEE PAGE 05–738)

→ There is no output: Go to step 7

→ There is output: Go to step 8

7	Problem Symptoms Table (SEE PAGE 05–729)

→ Check for fluid leakage and Go to step 10

8	DTC Chart (SEE PAGE 05–750)

9	Circuit Inspection (SEE PAGE 05–754 to 05–905)

10	Identification of Problem

11	**Repair**

12	**Confirmation Test**

End