# SOUND QUALITY IS BAD IN ALL MODES (VOLUME IS TOO LOW)

## INSPECTION PROCEDURE

| 1 | ADJUST SOUND QUALITY |
|---|---|

(a) Adjust the sound quality.
(1) Operate the radio receiver assy to adjust the sound quality.
**OK: Malfunction disappears.**
**Reference:**
**Check if the sound quality is the same with the same model of another vehicle.**

**NG** → **REPLACE RADIO RECEIVER ASSY (SEE PAGE 67–5)**

**OK**

**SYSTEM OK**