CD CANNOT BE EJECTED

INSPECTION PROCEDURE

1	PRESS "EJECT" AND CHECK OPERATION

(a) Press "EJECT" and check the operation.
(1) Press the CD EJECT switch of the radio receiver assembly for 2 seconds or more to see if the CD is ejected.
OK: CD is ejected.

HINT:
If the CD is not ejected, bring the vehicle in for repair.
Do not attempt to remove it by force.

NG → **REPLACE RADIO RECEIVER ASSY (SEE PAGE 67–5)**

OK

2	REPLACE CD WITH ANOTHER AND RECHECK

(a) Replace the CD with another and recheck.
(1) Check the installation condition of the radio receiver assembly.
OK: Installed properly.

NG → **REPLACE RADIO RECEIVER ASSY (SEE PAGE 67–5)**

OK

CD IS FAULTY