
05HBI–01

# NAVIGATION CHECK MODE (PARTS INFORMATION)


HINT:

- This mode displays product information on the navigation systems and discs.
- Illustrations may differ from the actual vehicle depending on the device settings and options. Therefore, some detailed areas may not be shown exactly the same as on the actual vehicle.


**1. Enter diagnostic mode (see page 05–1578).**




**2. Select ”Navigation Check” from the ”Diagnosis MENU” screen.**




**3. Select ”Parts Information” from the ”Navigation Check” screen.**




**4. Check the navigation and disc information when the ”Parts Information” screen is displayed.**

| Display | Contents |
|---|---|
| Navigation Manufacturer/*1 | Navigation ECU manufacturer name is displayed. |
| Navigation Version/*2 | Navigation ECU version is displayed. |
| Disc Manufacturer/*3 | Map disc manufacturer is displayed. |
| Disc Version/*4 | Map disc version is displayed. |