05IFM–01

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below and proceed to the page given for that circuit.

DTC No. (See Page)	Detection Item	Trouble Area
B1241 (05–1790)	Door Control Switch Circuit Diagnosis	• Power window regulator master switch assy (Door control switch) • Wire harness • Instrument panel J/B assy (Multiplex network body ECU)