05IIH–01

HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

- Use this procedure to troubleshoot the key reminder warning system.
- The intelligent tester II should be used in steps 3 and 5.

1	VEHICLE BROUGHT TO WORKSHOP

2	CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK

3	CHECK COMMUNICATION FUNCTION OF LARGE–SCALE BODY MULTIPLEX COMMUNICATION SYSTEM (BEAN)

(a) Use the intelligent tester II to check for normal function of the multiplex communication system.
  (1) (ECU unconnected, communication line malfunctioning) Without code outputs, proceed to A.
  (2) (ECU unconnected, communication line malfunctioning) With code outputs, proceed to B.

B	Go to MULTIPLEX COMMUNICATION SYSTEM (See page 05–2261)

A

4	PROBLEM SYMPTOMS TABLE (See page 05–2034)

(a) If the fault is not listed on the problem symptoms table, proceed to A.
(b) If the fault is listed on the problem symptoms table, proceed to B.

B	Go to step 7

A

5	OVERALL ANALYSIS AND TROUBLESHOOTING

(a) DATA LIST/ACTIVE TEST (see page 05–2038)
  (1) Inspection with the intelligent tester II (DATA LIST).
(b) Terminals of ECU (see page 05–2035).
(c) On–vehicle inspection (see page 05–2043).
(d) Inspection (see page 05–2044).

6	ADJUST, REPAIR OR REPLACE

7	CONFIRMATION TEST

END