05ICD–01

SYSTEM DESCRIPTION

- This system has been provided as standard equipment on RHD models.*
- The theft deterrent system uses the power door lock control system and wireless door lock remote control system parts. The theft deterrent system will activate when somebody attempts to forcibly enter the vehicle, open the engine hood, or when the battery terminals are disconnected and reconnected.
- The theft warning ECU controls this system.
- An intrusion sensor has been added. This sensor improves system performance in case an attempt is made to enter the vehicle by breaking a window.
- The warning specifications of this system are listed below.

▶Warning Specifications◀

Model		RHD*
Warning Method	Interior Lamp	Illuminating
	Hazard Warning Lamp	Flashing
	Vehicle Horn	Sounding (at approx. 0.4 second intervals)
	Self power Siren	Sounding (at the cycle of the self power siren)
	Door Lock Motor	Locks doors
Warning Time		27.5 sec.

*: Except Australia, Singapore and Hong Kong.