

FUEL SUCTION W/ PUMP & GAUGE TUBE ASSY (1NZ–FXE)

1111O–01

COMPONENTS




Fuel Suction Plate Sub–assy
Fuel pump Harness
Fuel Filter
◆ O–ring
Fuel Pump Spacer
Fuel Pump
Clip
Fuel Pressure Regulator Assy
Fuel Tube Joint No. 1
◆ Fuel Pressure Regulator O–ring
Fuel Filter Assy
◆ Clip
Fuel Suction Support No. 1
Fuel Sender Gauge Assy
◆ Non–reusable part
P
A86318