CHARGING SYSTEM (1NZ–FXE)

190UL–01

ON–VEHICLE INSPECTION

1. INSPECT BATTERY

NOTICE:

If the battery is dead or ” READY” does not light up, recharge the battery. Check the battery again before the vehicle is returned to the customer.

(a) Check the appearance.

(1) Check that the battery is not damaged or deformed.

If damaged or deformed, replace the battery (the dedicated battery for Prius).