PARKING BRAKE SYSTEM

PROBLEM SYMPTOMS TABLE

3300E–08

Use the table below to help find the cause of the problem. The likely causes are displayed in numerical order. Check each part in order and replace each part if necessary.

Symptoms	Suspected Area	See Page
Brake drag	1. Parking brake pedal travel (misadjusted)	33–2
	2. Parking brake wire (Sticking)	33–19 33–23 33–26 33–30
	3. Parking brake shoe clearance (misadjusted)	33–33
	4. Parking brake shoe (Cracked or distorted)	33–33
	5. Tension spring (Damaged)	33–33