W/RECEIVER CONDENSER ASSY

55194–01

ON–VEHICLE INSPECTION

1. INSPECT COOLER CONDENSER CORE

(a) If the fins of the condenser assy (w/ receiver) are dirty, clean them with water and dry them with compressed air.

NOTICE:

Do not damage the fins of the cooler condenser core.

(b) If the fins of the condenser assy (w/ receiver) are bent, straighten them using a screwdriver or pliers.

2. INSPECT LEAKAGE OF REFRIGERANT

(a) Using a halogen leak detector, check the pipe joints for gas leakage.

(b) Check the tightening torque of the joint if gas leakage is detected in a pipe joint.