
AIR CONDITIONING AMPLIFIER ASSY

55198–01

REPLACEMENT

1. REMOVE INSTRUMENT PANEL FINISH PANEL LOWER CENTER (SEE PAGE 71–13)
2. REMOVE AIR DUCT REAR NO.3 (SEE PAGE 55–18)



3. **REMOVE AIR CONDITIONING AMPLIFIER ASSY**

(a) Disconnect the connector.

(b) Remove the 2 screws and then the air conditioning amplifier assy.