

6714T–01


COMPONENTS



P

I40939


Steering Pad Switch RH
Navigation Antenna Assy
Network Gateway ECU
Power Point Socket Cover
Power Point Socket Assy
Steering Pad Switch LH
Power Outlet Socket Cover RR
Power Point Socket Assy RR
P
I38943


Instrument Panel Speaker Panel Sub–assy
Stereo Component Speaker Assy Front
Antenna Cord Sub–assy No.2
Antenna Cord Sub–assy
Antenna Pole Sub–assy
Amplifier Microphone Assy
Antenna (Cord / Pole Separate Type) Holder Assy
Front No.2 Speaker Assy
Antenna Nut
5.0 (51, 44 in.·lbf)
Rear Speaker Assy No.2
Front No.1 Speaker Assy
◆ Rivet
Rear Speaker Assy
◆ Rivet
Navigation ECU Cover
Disc Player Bracket No.2
Disc Player Bracket
Navigation ECU
Audio Amplifier Cover
Stereo Component Amplifier Assy
N·m (kgf·cm, ft·lbf) : Specified torque
◆ Non–reusable part
P
I38941