
ANTENNA POLE SUB–ASSY

67153–01

REPLACEMENT

HINT:

- COMPONENTS: see page 67–2
- Installation is in the reverse order of removal.



1. REMOVE ANTENNA POLE SUB–ASSY

(a) Remove the antenna pole sub–assy by turning it counter-clockwise.