
INNER REAR VIEW MIRROR ASSY

70124–01

REPLACEMENT

HINT:

The installation procedures are the removal procedures in reverse order.



1. REMOVE INNER REAR VIEW MIRROR ASSY

(a) Push the cover in the direction indicated by the arrows labeled (a) and remove it.

(b) While holding down the claw in the direction of the arrow labeled (b), slide the inner rear view mirror in the direction of the arrow labeled (c) and remove it.