CRUISE CONTROL MAIN SWITCH


8204O–01

REPLACEMENT

HINT:

Installation is in the reverse order of removal.

1. **PRECAUTION (SEE PAGE 60–1)**
2. **DISCONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 60–1)**
3. **REMOVE STEERING WHEEL COVER LOWER NO.2**
4. **REMOVE STEERING WHEEL COVER LOWER NO.3**
5. **REMOVE HORN BUTTON ASSY (SEE PAGE 60–20)**



6. **REMOVE CRUISE CONTROL MAIN SWITCH**
   (a) Disconnect the connector.
   (b) Remove the 2 screws and cruise control main switch.

7. **INSTALL HORN BUTTON ASSY (SEE PAGE 60–20)**
8. **CONNECT BATTERY NEGATIVE TERMINAL (SEE PAGE 19–2)**
9. **INSPECT HORN BUTTON ASSY (SEE PAGE 60–14)**
10. **INSPECT SRS WARNING LIGHT (SEE PAGE 05–1155)**
11. **PERFORM INITIALIZATION (SEE PAGE 01–29)**