

EPS
1
2
3
4
(BAT)
50A
EPS
(IG)
5A
ECU–IG
NO. 2
DLC3
<1–3>
z8(D)
Power Steering Motor Assembly
Power Steering
Motor
M
A33(A), G6(B), z7(C), z8(D)
Power Steering ECU Assembly
PIG
IG
TS
M1
M2
PGND
CANH
CANL
TRQV
TRQ1
TRQG
TRQ2
Torque Sensor
z7(C)
Power Steering Torque Sensor
Multiplex Communication
System (CAN)<2–3>
W–B
A2
(BAT)
7. 5A
ECU–B
NO. 2
(IG)
7. 5A
METER
IG+
5V IC
5V+B
Power
Steering
CAN CONTROLLER
CPU
CAN I/F
I/F
Buzzer
CANL
CANH
ET
G1(A)
Combination Meter Assembly
Multiplex Communication
System (CAN)<2–1>
BR
G7