

C6
C7
C18
C17
C8
C14
C16
D2
P1
a3
C9
a2
a4
* 3:Before Dec. 2013 Production
* 4:From Dec. 2013 Production
* 7:Before Jun. 2017 Production
* 8:From Jun. 2017 Production
* 9:Before Jul. 2019 Production
* 10:From Jul. 2019 Production
C5
C3
C2
C1
C21
C20
E1
C11 (*3)
C29 (*4)
A88 (*9)
A92 (*10)
C25
B1
C28
(*9) A89
(*10) A93
(*9) A90
(*10) A95
A91 (*9)
A96 (*10)
C27
C22
E2
z4
D1
C15
C4
C12
C19
C23
C13
C24
a5 (*8)
a1 (*7)
C26

A 88 Front Turn Signal Light Assembly RH
A 89 Front Turn Signal Light Assembly LH
A 90 Front Turn Signal Light Assembly LH
A 91 Front Turn Signal Light Assembly RH
A 92 Front Turn Signal Light Assembly RH
A 93 Front Turn Signal Light Assembly LH
A 95 Front Turn Signal Light Assembly LH
A 96 Front Turn Signal Light Assembly RH

B 1 Inverter with Converter Assembly

C 1 Fuel Injector Assembly No. 1
C 2 Fuel Injector Assembly No. 2
C 3 Fuel Injector Assembly No. 3
C 4 Fuel Injector Assembly No. 4
C 5 Ignition Coil No. 1
C 6 Ignition Coil No. 2
C 7 Ignition Coil No. 3
C 8 Ignition Coil No. 4
C 9 ECM
C 11 Crank Position Sensor
C 12 Throttle Body Assembly with Motor
C 13 Cam Position Sensor
C 14 E.F.I. Engine Coolant Temperature Sensor
C 15 E.F.I. Vacuum Sensor Assembly
C 16 Oxygen Sensor (Bank 1 Sensor 2)
C 17 Air Fuel Ratio Sensor (Bank 1 Sensor 1)
C 18 EGR Valve Assembly
C 19 Purge VSV
C 20 Camshaft Timing Oil Control Valve Assembly
C 21 Intake Mass Air Flow Meter Sub-Assembly
C 22 Compressor with Motor Assembly
C 23 Shift Lever Position Sensor
C 24 Hybrid Vehicle Transaxle Assembly
C 25 Hybrid Vehicle Transaxle Assembly
C 26 Hybrid Vehicle Transaxle Assembly
C 27 Engine Water Pump Assembly
C 28 Inverter with Converter Assembly
C 29 Crank Position Sensor

D 1 Compressor with Motor Assembly
D 2 Inverter with Converter Assembly


E 1 Knock Control Sensor (Bank 1)
E 2 Engine Oil Pressure Switch Assembly

P 1 Inverter with Converter Assembly


a 1 Hybrid Vehicle Transaxle Assembly
a 2 Inverter with Converter Assembly
a 3 Hybrid Vehicle Transaxle Assembly
a 4 Inverter with Converter Assembly
a 5 Hybrid Vehicle Transaxle Assembly

z 4 Cooling Fan ECU , Cooling Fan Motor


A 88
Gray




A 89
Gray




A 90
Gray




A 91
Gray




A 92
Gray




A 93
Gray




A 95
Gray




A 96
Gray




B 1




C 1
Black




C 2
Gray




C 3
Black




C 4
Gray




C 5
Black




C 6
Gray




C 7
Black




C 8
Gray




C 9
Black



C 11
Black



C 12
Black




C 13
Black



C 14
Black



C 15
Black



C 16
Gray




C 17
Gray



C 18
Black




C 19
Black




C 20
Black




C 21
Black




C 22
Black




C 23
Gray




C 24
Black




C 25
Black




C 26
Black




C 27
Black




C 28
Black




C 29
Black




D 1
Orange



D 2
White




E 1
Black




E 2
Gray




P 1
White




a 1
Orange




a 2
Orange




a 3
Orange



a 4
Orange



a 5
Orange



z 4
Gray

