

Roof Wire
G7
G4
G3
Engine Room
Main Wire
Instrument Panel
No. 2 Wire
Engine Room
Main Wire
Front Door
LH Wire
G6
G2
Floor Wire
A2
Instrument Panel
Wire
Front Door
RH Wire
G5
G1
Floor Wire
Floor Wire