

Roof Wire
Front Door Wire RH
Connector Wire
Front Door RH No. 2 Wire
Rear Door No. 1 Wire
Back Door No. 1 Wire
Front Door Wire LH
Front Door LH No. 2 Wire
Rear Door No. 2 Wire
S1
S2
V1
Floor No. 2 Wire
Floor Wire
Skid Control Sensor Wire
R1
R2
Skid Control Sensor Wire