
* 9:Before Dec. 2017 Production
* 10:From Dec. 2017 Production




S 5 Front Door Courtesy Light Switch Assembly RH
S 6 Front Pretensioner RH (Front Seat Outer Belt Assembly RH)
S 7 Front Pre-Crash Seat Belt Motor RH (Front Seat Outer Belt Assembly RH)
S 8 Side Airbag Sensor Assembly RH
S 10 Rear Door Courtesy Light Switch Assembly RH
S 11 Curtain Shield Airbag Assembly RH
S 12 Door Control Receiver
S 17 HV Battery Thermometer (Thermistor Assembly)
S 18 Rear Combination Light Assembly RH
S 20 Junction Connector
S 21 Outside Luggage Electrical Key Antenna (Electrical Key Antenna)
S 24 No. 2 Side Airbag Sensor Assembly RH
S 25 Rear Height Control Sensor Sub-Assembly RH
S 26 No. 2 Indoor Electrical Key Antenna Assembly
S 27 Rear Power Point Socket Assembly
S 28 Rear Seat 3 Point Type Belt Assembly RH
S 29 Rear No. 2 Seat Inner Belt Sub-Assembly
S 30 Battery Cooling Blower Assembly
S 31 Glass Breakage Sensor RH (Quarter Window Assembly RH)
S 32 Glass Breakage Sensor RH (Quarter Window Assembly RH)
S 33 Theft Warning Siren Assembly
S 35 Glass Breakage Sensor RH (Quarter Window Assembly RH)
S 36 HV Battery Thermometer (Thermistor Assembly)


S 5
Black




S 6
Black



S 7
White




S 8
Yellow




S 10
Black



S 11
Black




S 12
Blue




S 17
Black




S 18
White




S 20
White




S 21
White




S 24
Yellow




S 25
Black




S 26
White




S 27
White




S 28
Black



S 29
Gray



S 30
White




S 31
White




S 32
White



S 33
Black



S 35
White



S 36
Black

