


* 3:Radio & Display Receiver Type
* 16:Before Nov. 2014 Production
  Navigation Receiver Type
* 17:From Nov. 2014 Production
  Navigation Receiver Type

H 3 Front Passenger Side Squib Circuit (Instrument Panel Passenger without Door Airbag Assembly)

I 1 Automatic Light Control Sensor
I 2 Front No. 2 Speaker Assembly RH
I 3 Front No. 2 Speaker Assembly LH
I 4 Instrument Panel Speaker RH (No. 1 Instrument Panel Speaker Panel Sub-Assembly)
I 5 Instrument Panel Speaker LH (No. 2 Instrument Panel Speaker Panel Sub-Assembly)
I 6 Instrument Panel Speaker RH (No. 1 Instrument Panel Speaker Panel Sub-Assembly)
I 7 Instrument Panel Speaker LH (No. 2 Instrument Panel Speaker Panel Sub-Assembly)


R 1 Airbag ECU Assembly

S 1 Airbag ECU Assembly


Y 1 Radio & Display Receiver Assembly
Y 2 Radio & Display Receiver Assembly
Y 3 Extension Module Assembly
Y 4 Extension Module Assembly

z 8 Driver Side Squib Circuit (Horn Button Assembly) , Spiral with Sensor Cable Sub-Assembly
z 9 Spiral with Sensor Cable Sub-Assembly , Steering Pad Switch Assembly
z 10 Cruise Control Main Switch , Spiral with Sensor Cable Sub-Assembly
z 11 A/C Amplifier Assembly , A/C Blower Assembly
z 14 Power Steering ECU Assembly , Power Steering Torque Sensor
z 15 Power Steering ECU Assembly , Power Steering Motor Assembly
z 16 Power Steering ECU Assembly , Power Steering Motor Assembly


H 3
Orange




I 1
Black




I 2
White




I 3
White




I 4
Black




I 5
Black




I 6
Black




I 7
Black




R 1
Yellow




S 1
Yellow




Y 1
White




Y 2
White




Y 3
Black




Y 4
White




z 8
Orange




z 9
White




z 10
White




z 11
White



z 14
White



z 15
White



z 16
White

