

* 2:Navigation Receiver Type
* 3:Radio & Display Receiver Type




H	3	Front Passenger Side Squib Circuit (Instrument Panel Passenger without Door Airbag Assembly)
I	1	Automatic Light Control Sensor
I	2	Front No. 2 Speaker Assembly RH
I	3	Front No. 2 Speaker Assembly LH
I	6	Instrument Panel Speaker RH (No. 1 Instrument Panel Speaker Panel Sub-Assembly)
I	7	Instrument Panel Speaker LH (No. 2 Instrument Panel Speaker Panel Sub-Assembly)
R	1	Airbag ECU Assembly
S	1	Airbag ECU Assembly
z	8	Driver Side Squib Circuit (Horn Button Assembly) , Spiral with Sensor Cable Sub-Assembly
z	9	Spiral with Sensor Cable Sub-Assembly , Steering Pad Switch Assembly
z	10	Cruise Control Main Switch , Spiral with Sensor Cable Sub-Assembly
z	11	A/C Amplifier Assembly , A/C Blower Assembly
z	14	Power Steering ECU Assembly , Power Steering Torque Sensor
z	15	Power Steering ECU Assembly , Power Steering Motor Assembly
z	16	Power Steering ECU Assembly , Power Steering Motor Assembly


H 3
Orange




I 1
Black




I 2
White




I 3
White




I 6
Black




I 7
Black




R 1
Yellow




S 1
Yellow




z 8
Orange




z 9
White




z 10
White




z 11
White



z 14
White



z 15
White



z 16
White

