

Headlight Cleaner
Power Outlet
1
2
3
4
(BAT)
30A
H–LP
CLN
(IG)
10A
ECU–IG
NO. 2
(ACC)
15A
PWR
OUTLET
(ACC)
15A
CIG
A54
Junction
Connector
A44
Headlight Cleaner Relay
IG
PB
FRWA
H
HDLO
E
A43
Headlight Cleaner
Motor and Pump
Assembly
Windshield Wiper Switch
Assembly<20–2>
L153
Headlight Cleaner
Switch Assembly
A55
Junction
Connector
Integration Relay
<3–2>
L125
Center Power Outlet
Socket Assembly
L24
Power Outlet
Socket Assembly
L93
Junction
Connector
A2
L1