



* 3:w/ Rotation Angle Sensor
* 4:w/o Rotation Angle Sensor
A51
A50
A21
A22
A27
(*4)
A53
A54
A56
A25
A28
A48
A55
A24
A23
A67
A68
A27
(*3)
A29
A52
A20
A19

A 19 Quick Heater Assembly
A 20 Quick Heater Assembly
A 21 Power Management Control ECU
A 22 Power Management Control ECU
A 23 Transmission Control ECU Assembly
A 24 Transmission Control ECU Assembly
A 25 Parking Brake Switch Assembly
A 27 Power Steering ECU Assembly
A 28 Stop Light Control Relay Assembly
A 29 Accelerator Pedal Sensor Assembly
A 48 Headlight Leveling ECU Assembly
A 50 Junction Connector
A 51 Junction Connector
A 52 Junction Connector
A 53 Junction Connector
A 54 Junction Connector
A 55 Junction Connector
A 56 Junction Connector
A 67 Stop Light Switch Assembly
A 68 Brake Pedal Stroke Sensor Assembly


A 19
White




A 20
White




A 21
Gray




A 22
Gray



A 23
White




A 24
White




A 25
White




A 27
Gray




A 28
Black




A 29
Black




A 48
White




A 50
White




A 51
White




A 52
Black




A 53
Black




A 54
Black




A 55
Black



A 56
White



A 67
White



A 68
Black

