





L12
Yaw Rate
Sensor Assembly




- * 1 : w/ Navigation Receiver Assembly Type
- * 2 : w/ Radio & Display Receiver Assembly Type











A 2

Black




A 23

White




A 56

Black




A 57

Gray




L 4

White




L 5

Gray




L 6


Gray




L 7
White




L 12
Black




L 13
Yellow




L 14
White




L 23
White




L 27
White




L 42
White




L 45
White




L 54
White




L 55
White




L 56
White



L 59
Black




L 79
White




L 81
White




L 82
White




L 83
White




L 84
White




L 85
White




L 86
Black




L 88
White




L 89
White




L 90
White



L 91
White




L 92
White




L 93
White




L 94
White




L 95
White




L 96
White




L 97
White




L 98
White




L 99
White




L100
White




L101
White




L102
White




L103
White




L107
White




L117
Black




S 21
White




AL3
White



AL4
Black



AL8
White



LS1
White

