






























Position of Parts in Instrument Panel <LHD>




L 100	Junction Connector
L 101	Junction Connector
L 102	Junction Connector
L 103	Fuse Block
L 108	Pre-Crash Safety System Cancel Switch Assembly
L 124	Transmission Shift Main Switch
L 125	Combination Meter Assembly
L 126	Shift Lever Position Sensor (Shift Lock Control Unit Assembly)
L 127	No. 2 Shift Lever Position Sensor (Shift Lock Control Unit Assembly)
L 129	Shift Position Indicator Light (Shift Lock Control Unit Assembly)
L 132	Junction Connector
L 133	Junction Connector
L 134	Navigation Receiver Assembly
L 135	Radio & Display Receiver Assembly
L 136	Parking Assist ECU
L 137	Navigation Receiver Assembly
L 141	Combination Meter Assembly
L 142	Headlight Leveling Switch
L 146	Windshield Wiper Relay Assembly
L 147	Head-Up Display Switch Assembly
L 148	Airbag Cut Off Switch Cylinder Sub-Assembly
L 149	Head-Up Display Assembly
L 153	Rear Fog Light Relay
L 154	Radio Receiver Assembly
L 155	Radio Receiver Assembly
L 156	Radio Receiver Assembly
L 157	Amplifier Antenna Assembly
L 158	No. 1 Interior Illumination Light Assembly LH
L 160	Head-Up Display Assembly
L 161	Junction Connector
L 162	Navigation Receiver Assembly
L 163	Radio & Display Receiver Assembly
L 164	Tire Pressure Warning Reset Switch (No. 1 Tire Pressure Warning Switch)
L 166	Radio & Display Receiver Assembly
L 167	Radio & Display Receiver Assembly
L 168	Radio & Display Receiver Assembly
L 169	Radio & Display Receiver Assembly

Position of Parts in Instrument Panel <LHD>




Position of Parts in Instrument Panel <LHD>


L161
Gray




L162
Gray




L163
Gray




L164
White




L166
White



L167
White



L168
White



L169
White

