



















Position of Parts in Instrument Panel <RHD>

- * 1:Refer to the Service Bulletin for the installation position of the parts.
- * 6:w/ Headlight Cleaner
- * 7:Light Control Switch LH Side Type
- * 8:Light Control Switch RH Side Type
- * 15:Before Nov. 2014 Production Navigation Receiver Type
- * 24:Before Nov. 2014 Production Radio & Display Receiver Type
- * 25:Before May 2016 Production
- * 26:From May 2016 Production
- * 28:From Nov. 2014 Production until Dec. 2017 Production




- L 40 Navigation Receiver Assembly
- L 41 Radio & Display Receiver Assembly
- L 43 Power Switch
- L 44 Cooler (Room Temperature Sensor) Thermistor
- L 46 Skid Control Buzzer Assembly
- L 47 Headlight Dimmer Switch Assembly
- L 48 Windshield Wiper Switch Assembly
- L 49 Windshield Wiper Switch Assembly
- L 51 Steering Sensor
- L 52 Spiral with Sensor Cable Sub-Assembly
- L 53 Spiral with Sensor Cable Sub-Assembly
- L 54 Power Steering ECU Assembly
- L 56 Parking Assist Pre Support Switch Assembly
- L 57 Hazard Warning Signal Switch Assembly
- L 58 Headlight Cleaner Switch Assembly
- L 60 Driving Support ECU Assembly
- L 61 DLC3
- L 62 Certification ECU Assembly
- L 63 Certification ECU Assembly
- L 64 Parking Assist ECU
- L 65 Parking Assist ECU

Position of Parts in Instrument Panel <RHD>




Position of Parts in Instrument Panel <RHD>

L 63
White



L 64
White



L 65
Black

