


















Position of Parts in Body (RHD)



O1 Rain Sensor
O2 Map Light Assembly
O3 Map Light Assembly
O4 Map Light Assembly
O5 No. 1 Room Light Assembly
O6 Map Light Assembly
O7 Forward Recognition Camera
O9 Inner Rear View Mirror Assembly
O10 Sliding Roof Control ECU (Sliding Roof Drive Gear Sub-Assembly)
O11 Visor Assembly RH
O12 Vanity Light Assembly RH
O13 Visor Assembly LH
O14 Vanity Light Assembly LH
O15 Theft Warning Ultrasonic Sensor
O16 No. 26 Junction Connector
O17 Forward Recognition with Heater Hood Sub-Assembly

P1 Rear Ultrasonic Sensor Side LH
P2 Rear Ultrasonic Sensor Side RH
P3 Rear Ultrasonic Sensor Corner RH
P4 Rear Ultrasonic Sensor Center RH
P5 Rear Ultrasonic Sensor Center LH
P6 Rear Ultrasonic Sensor Corner LH
P7 Rear Light Assembly RH
P8 Rear Light Assembly LH
P9 Rear Light Assembly RH
P10 Rear Light Assembly LH
P11 Rear Light Assembly RH
P12 Rear Light Assembly LH

Position of Parts in Body (RHD)



Position of Parts in Body (RHD)

