



Position of Parts in Body (RHD)



p1	HV Battery Assembly
q1	HV Battery Assembly
r1	Hybrid Battery Terminal Block , HV Battery Assembly
r2	HV Battery Assembly
s1	Hybrid Battery Terminal Block , HV Battery Assembly
s2	HV Battery Assembly
t1	HV Battery Assembly
t2	No. 2 HV Battery Junction Block Assembly
t3	No. 2 HV Battery Junction Block Assembly
t4	No. 2 HV Battery Junction Block Assembly
t5	No. 1 HV Battery Junction Block Assembly
t6	HV Battery Heater Relay
t7	No. 1 HV Battery Junction Block Assembly
t8	No. 1 HV Battery Junction Block Assembly
t9	Inter Lock Switch (Service Plug Grip)
t10	HV Battery Assembly
t11	HV Battery Assembly
t12	HV Battery Assembly
t13	HV Battery Assembly
t14	Battery ECU Assembly
t15	HV Battery Heater Sub-Assembly
t16	HV Battery Heater Sub-Assembly
z20	Battery ECU Assembly , HV Battery Assembly
z21	Battery ECU Assembly , HV Battery Assembly
z22	Battery ECU Assembly , HV Battery Assembly
z23	Battery ECU Assembly , HV Battery Assembly
z24	Battery ECU Assembly , HV Battery Assembly

Position of Parts in Body (RHD)



Position of Parts in Body (RHD)

