


Position of Parts in Instrument Panel (LHD)
















- * 5:Korea
- * 6:Europe
- * 7:w/ Solar Battery Charger System
- * 8:w/o Solar Battery Charger System




Position of Parts in Instrument Panel (LHD)

I50	No. 2 Power Outlet Socket Assembly
I51	Shift Lock Control Unit Assembly
I52	No. 2 Combination Switch Assembly
I53	Power Switch
I54	Cooler (Room Temperature Sensor) Thermistor
I55	A/C Control Assembly
I56	Transmission Shift Main Switch
I57	Power Steering ECU Assembly
I58	Spiral Cable with Sensor Sub-Assembly
I59	Airbag Sensor Assembly
I60	A/C Amplifier Assembly
I61	A/C Amplifier Assembly
I62	Network Gateway ECU
I63	Stereo Component Amplifier Assembly
I64	Stereo Component Amplifier Assembly
I67	Headlight Dimmer Switch Assembly
I68	Windshield Wiper Switch Assembly
I69	Windshield Wiper Switch Assembly
I70	No. 2 Cooler Thermistor
I71	No. 3 Cooler Thermistor
I73	No. 1 CAN Junction Connector
I74	No. 1 CAN Junction Connector
I75	No. 2 CAN Junction Connector
I76	No. 3 CAN Junction Connector
I77	No. 4 CAN Junction Connector
I78	No. 5 CAN Junction Connector
I79	No. 6 Junction Connector


Position of Parts in Instrument Panel (LHD)




Position of Parts in Instrument Panel (LHD)




90980-12460




90980-12359




90980-12358





90980-12937




90980-12808



90980-12A58







90980-12372



90980-12372

Position of Parts in Instrument Panel (LHD)



Position of Parts in Instrument Panel (LHD)

