



Position of Parts in Instrument Panel (LHD)

* 5:Korea




V1	Hazard Warning Signal Switch Assembly
o3	Radio & Display Receiver Assembly
o4	Radio & Display Receiver Assembly
o5	Navigation ECU
o6	Radio & Display Receiver Assembly
o7	Navigation ECU
o8	Radio & Display Receiver Assembly
o9	Navigation ECU
o10	Radio & Display Receiver Assembly
o11	Navigation ECU
o12	Radio & Display Receiver Assembly
o13	Navigation ECU
z1	A/C Harness Assembly , A/C Amplifier Assembly
z3	Steering Pad Switch Assembly , Spiral Cable with Sensor Sub-Assembly
z4	Cruise Control Switch Wire , Spiral Cable with Sensor Sub-Assembly
z5	Driver Side Squib Circuit (Horn Button Assembly) , Spiral Cable with Sensor Sub-Assembly
z6	Driver Side Squib Circuit (Horn Button Assembly) , Spiral Cable with Sensor Sub-Assembly
z7	Heater Control Assembly, Spiral Cable with Sensor Sub-Assembly
z8	Electric Power Steering Column Sub-Assembly , Power Steering ECU Assembly
z26	Rechargeable Battery Assembly , Thermistor (Rechargeable Battery Assembly)


Position of Parts in Instrument Panel (LHD)




90980-12550




90980-12221




90980-12183




90980-12976




90980-12960




90980-12960




90980-12A81




90980-12A81




90980-12960




90980-12960




90980-12221




90980-12976




90980-12551




90980-12559




90980-12360




82824-47B50




82824-47B80



90980-12A94



90980-12899



90980-12551