




Tire Pressure Warning System



Tire Pressure Warning System




Tire Pressure Warning System




Tire Pressure Warning System

- * 3 : w/ Navigation System
- * 4 : w/o Navigation System


I6(A)
Combination Meter Assembly




Tire Pressure Warning System




90980-12B78




90980-12557




90980-12909




90980-12370



90980-12555





90980-10997





90980-12372

I79
Gray





90980-12372
(RHD)

I79
White





90980-12372
(LHD)

I80
Gray



90980-12372


I84
White



90980-12372


Tire Pressure Warning System

I88
White




90980-12372
(RHD)

I88
Gray



90980-12372
(LHD)


I96
White



90980-12555

I97


White



90980-10997

N14


White



90980-12552

N54


White



90980-12B77

N96


Black



90980-12B54

N98

Black



90980-12B54

Tire Pressure Warning System

