




* 1:Europe, Before Aug. 2008 Production
  Except Europe
* 2:From Aug. 2008 Production
  Except Europe

K 6 Yaw Rate Sensor
K 7 Deceleration Sensor
K 8 Door Courtesy SW (Front LH)
K 9 Pretensioner (LH)
K 10 Side Airbag Sensor (Front LH)
K 11 Door Courtesy SW (Rear LH)
K 12 Side Airbag Sensor (Rear LH)
K 13 Rear Combination Lamp (RH)
K 14 Curtain Shield Airbag Squib (LH)
K 15 Rear Combination Lamp (LH)
K 16 Diode (Room Lamp)
K 17 Power Outlet Socket (Rear)
K 18 Door Courtesy SW (Back Door)
K 20 Junction Connector
K 21 Junction Connector
K 23 Electrical Key Oscillator (Inside Luggage Room)
K 23 Electrical Key Oscillator (Inside Luggage Room)
K 24 Tire Pressure Warning Antenna (Rear)
K 25 Yaw Rate Sensor
K 26 Side Airbag Sensor (Rear LH)
K 27 Junction Connector
K 28 Speed Sensor (Rear LH)
K 29 Speed Sensor (Rear RH)

K 6
Black




K 7
White




K 8
White



K 9
Yellow




K 10
Yellow



K 11
White




K 12
Yellow



K 13
Gray



K 14
Black




K 15
Gray



K 16
Black




K 17
White




K 18
White




K 20
Black



K 21
White




K 23
White




(Before Aug. 2007 Production)

K 23
White




(From Aug. 2007 Production)

K 24
Blue




K 25
Black



K 26
Yellow



K 27
Gray



K 28
White



K 29
White

