

A5
Instrument Panel
No.2 Wire
E5
Instrument Panel
Wire Assembly
Roof
Wire
Engine Room
Main Wire
Engine Room
Main Wire
A6
Instrument
Panel Wire
Front Door
RH Wire
E4
Front Door
LH Wire
Floor No.2
Wire
E1
Floor Wire
E2
Solenoid Wire
E3
Illumination
Wire
Floor
Wire
Fuel Gauge
Wire
Floor No.2
Wire