

Instrument Panel Wire Assembly
E2
Instrument Panel Wire
Instrument Panel No.2 Wire
A5
Roof Wire
Engine Room Main Wire
A6
Front Door LH Wire
E1
Floor Wire
Fuel Gauge Wire
Engine Room Main Wire
E5
Front Door RH Wire
E4
Floor Wire
Floor No.2 Wire
Illumination Wire
E3
Solenoid Wire
Floor No.2 Wire