

L1
L12
f1
P9
P1
K22
P8
K3
K19
K4
P6
P3
P7
e1
P2
P4
P5

K 3 Front Seat Inner Belt (Driver's Side)
K 4 Seat Heater (LH)
K 19 Front Seat Inner Belt (Front Passenger's Side)
K 22 Junction Connector

L 1 Seat Heater (RH)
L 12 Front Seat Inner Belt (Front Passenger's Side)

P 1 Power Seat Motor (Driver's Seat Slide Control)
P 2 Power Seat Motor (Driver's Seat Lifter Control)
P 3 Power Seat Motor (Driver's Seat Front Vertical Control)
P 4 Power Seat Motor (Driver's Seat Reclining Control)
P 5 Power Seat Motor (Driver's Seat Lumbar Support Control)
P 6 Power Seat SW (Driver's Seat)
P 7 Power Seat SW (Lumbar Support)
P 8 Junction Connector
P 9 Seat Heater (LH)

e 1 Side Airbag Squib (LH)

f 1 Side Airbag Squib (RH)


K 3
White




K 4
White



K 19
White




K 22
White




L 1
White




L 12
White




P 1
Black




P 2
Black




P 3
Black




P 4
Black




P 5
Black




P 6
Black



P 7
White




P 8
Gray



P 9
White



e 1
White



f 1
White

