
■ FORCED WIPING DURING START-OFF FUNCTION

- When the wiper control switch is in the AUTO position, the system is sensing raindrops, and the vehicle speed has changed from a maximum of 4 km/h to a minimum of 6 km/h, the wiper ECU determines that the vehicle has started off. At this time, the wiper ECU forces the wipers to operate once.
- This control forces the wipers to operate every time the wiper ECU has determined a start-off.



01NBE93Y