
■ ACTUATION AREA

The functions of the smart entry & start system only work when the key is in the actuation area formed by the five oscillators.

- The front room oscillator forms the actuation area of the start function.
- Two door oscillators and back door outer oscillator form the actuation area of the entry function.



- The front room oscillator forms the actuation area in the upper sections of the driver seat and front passenger seat.
- The luggage room oscillator forms the actuation area in the upper section of the rear seat and in the luggage room.