| Item | | (1) | (2) | (3) | (4) | (5) | With DPF | Without DPF |
|---|---|---|---|---|---|---|---|---|
| Serpentine Belt Drive System | A serpentine belt drive system is used. | | | ○ | ○ | | ○ | ○ |
| Engine Control System | A pilot injection control system is used. | ○ | | | | | ○ | ○ |
| | An oil maintenance management system is used. | | | | ○ | | ○ | ○ |
| | A charging control system is used. | | | | | ○ | ○ | ○ |
| | A catalyst support control is used. | | | | | ○ | ○ | — |

## 3. Engine Proper

### Cylinder Head

A hole for installing the exhaust fuel addition injector is located on the No.4 exhaust port of the cylinder head.

