
RADIATOR SUPPORT (ASSY)


F24654A


With the radiator upper support removed.

Symbol meaning

REMOVAL	: Remove Weld Points
INSTALLATION	: MIG Plug Weld

F24654B

REMOVAL·INSTALLATION



F24654

REMOVAL POINT

1 *1: Bolt

INSTALLATION POINT

1 Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.

2 Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)