QUARTER INNER LOWER PANEL (ASSY)


F24717A


With the back door opening trough removed.

Symbol meaning	
REMOVAL	▲ : Remove Weld Points
INSTALLATION	■ : MIG Plug Weld


F24717B

REMOVAL·INSTALLATION

[LH]



[RH]



F24717

INSTALLATION POINT

1 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.