

■LAYOUT OF MAIN COMPONENTS




With Air Conditioner Models




LHD Models

*1: Only for Models with Automatic Air Conditioner
*2: Only for Models with Power Heater
*3: Only for Models with PTC Heater in Manual Air Conditioner



01NBE19Y

Manual Air Conditioner LHD Models



01NBE20Y

Automatic Air Conditioner LHD Models

*: Only for Models with PTC Heater

BE