
■LAYOUT OF MAIN COMPONENTS



LHD Models

*1: Only for 1AZ-FE and 2AZ-FE Engines
*2: Only for 2AD-FTV and 2AD-FHV Engines
*3: Only for Models with VSC System
*4: Only for A/T Models
*5: Only for M/T Models