
■CVT FLUID WARMER

- The CVT fluid warmer uses engine coolant to warm up the CVT fluid quickly. Consequently, the friction losses of the CVT are quickly reduced, thus improving fuel economy.
- After warming up the CVT fluid, the engine coolant flows into the CVT fluid warmer to cool down the CVT fluid.



■CVT FLUID FILLING PROCEDURES

A CVT fluid filling procedure is used in order to improve the accuracy of the CVT fluid level when the CVT is being repaired or replaced. For details about the CVT fluid filling procedures, refer to the TOYOTA RAV4 Repair Manual.

