

■INTAKE AND EXHAUST SYSTEM

1. EGR Cooler

The engine coolant exhaust pipes have been made into a single pipe on models with automatic transaxle.




Models with Automatic Transaxle




Models with Manual Transaxle

2. Turbocharger

On models with automatic transaxle, the turbocharger is cooled by the engine oil. On models with manual transaxle, the turbocharger is cooled by the engine oil and the water.




01NEG257I




288EG40Y

Models with Automatic Transaxle



01NEG256I



288EG77Y

Models with Manual Transaxle