
■ ENGINE CONTROL SYSTEM

Construction

The configuration of the engine control system is as shown in the following chart:




*1: Models with DPF catalyst

*2: Models with cruise control system

(Continued)

01NEG248I



01NEG260I

*1: Models with automatic transaxle
*2: Models with manual transaxle
*3: Models without entry & start system
*4: Models with entry & start system
*5: Models with air conditioning
*6: Powertrain bus
*7: V bus

NF